

Know Your Tuner

Important installation notes

Congratulations!

Here is your new purchase of high quality HRT600 tuner.

This product has a limited warranty of 12 months for parts and labor.

Technical Support and this warranty provided by Firebird Systems, Inc. Please use the technical support request form on your purchasing website.

All support requests must be e-mailed and registered by us. We are not responsible for unregistered telephone requests.

A. Connections

Your tuner has 2 connection types to your TV:

1. Main Connection – VGA Out or Display Out

2. Secondary Connection - Composite Video or TV Out (yellow RCA socket)

The tuner's configuration and setup **MENU** is available through the main VGA connection only. It is not available through the secondary connection, a regular Composite Video (CV) connection.

To run the required configuration setup, use the supplied VGA cable to connect between the tuner and your TV or Video monitor.

If you do not have VGA connection on your TV or TV monitor, you may use a computer monitor to run the setup.

After you run the setup (channels scanning, resolution and audio configuration) you may switch to the secondary connection – CV.

Please take notice that up-scaling the picture to higher resolutions is available through the VGA connection only and is relative to the monitor/TV native resolutions. The resolution available through the CV connection is regular TV resolution 480i.

Connecting to CV output before running setup will result in static noise – no audio and no menu access.

B. Channel scanning

Detailed information on how to run the SCAN feature is available in the user's manual page 8.

For maximum channels scanning use NORMAL Scanning instead of Fast Scanning

Enjoy!